# HFD27

# SUBMINIATURE DIP RELAY





### Features

COIL

Coil power

UL/CUL

**COIL DATA** 

Coil

048-M

Coil

48

ΤÜV

Temperature rise

- 2 Form C configuration
- High switching capacity: 125VA/60W
- Matching 16 pin IC socket
- Bifurcated contacts

SAFETY APPROVAL RATINGS

Notes: 1) All values unspecified are at 85°C.

Standard type (280mW to 580mW) Initial

Pick-up

Voltage

can be available upon request.

2) Only typical loads are listed above. Other load specifications

Initial Drop-out

Voltage

4.8

Max.

56.0

Epoxy sealed for automatic-wave soldering and cleaning

### **RoHS** compliant

Sensitive: Approx. 200mW

65K max.

2A 30VDC

1A 125VAC 2A 30VDC

1A 125VAC

at 23°C

Coil

Resistance

Ω

High Sensitive: Approx. 150mW

Standard: Approx. 280mW to 580mW

# CONTACT DATA

File No.:CQC09002033393

File No.:R50316277

(CQC)

2C
100mΩ max. (at 10mA 30mVDC)
AgNi + Au plated
1A 125VAC, 2A 30VDC
240VAC / 120VDC
2A
125VA / 60W
10mV 10µA
1x10 <sup>8</sup> 0PS
1 x 10 <sup>5</sup> ops (1A 125VAC, Resistive load, at 85°C, 1s on 9s off)

Notes: 1) Min. applicable load is reference value. Please perform the confirmation test with the actual load before production since reference value may change according to switching frequencies, environmental conditions and expected contact resistance and reliability.

2) Electric endurance data are collected in one pair CO contact test.

## **CHARACTERISTICS**

resistance	1000MΩ (at 500VDC)	
Between	coil & contacts	1500VAC 1min
Detruces		M, S type: 1000VAC 1min
Between	open contacts	H type: 750VAC 1min
ne (at nom	7ms max.	
me (at nom	4ms max.	
emperature	-40°C to 85°C	
	5% to 85% RH	
esistance	10Hz to 55Hz 1.5mm DA	
-1	Functional	196m/s <sup>2</sup>
stance	Destructive	980m/s <sup>2</sup>
n	PCB (DIP)	
t	Approx. 5g	
on	Plastic sealed	
	Between Between me (at nom me (at nom emperature esistance istance n t	Between coil & contacts Between open contacts ne (at nomi. volt.) me (at nomi. volt.) emperature esistance stance functional Destructive n t

Notes: 1) The data shown above are initial values. 2) UL insulation system: Class A.



36.0

HONGFA RELAY

ISO9001, IATF16949 , ISO14001, OHSAS18001, IECQ QC 080000 CERTIFIED

2023 Rev. 1.00

4000 x (1±10%)

# **COIL DATA**

### at 23°C

High sensitive type (150mW)					Sensitiv	/e type (	200mW)				
Coil Code	Coil Voltage VDC <sup>1)</sup>	Initial Pick-up Voltage VDC <sup>1)</sup>	Initial Drop-out Voltage VDC	Max. Voltage VDC <sup>4)</sup>	Coil Resistance Ω	Coil Code	Coil Voltage VDC <sup>1)</sup>		Initial Drop-out Voltage VDC min.	Max. Voltage VDC <sup>4)</sup>	Coil Resistance Ω
003-H	3	2.4	0.3	7.0	60 x (1±10%)	003-S	3	2.25	0.3	6	45 x (1±10%)
005-H	5	4.0	0.5	11.5	167 x (1±10%)	005-S	5	3.75	0.5	10	125 x (1±10%)
006-H	6	4.8	0.6	13.8	240 x (1±10%)	006-S	6	4.50	0.6	12	180 x (1±10%)
009-H	9	7.2	0.9	20.8	540 x (1±10%)	009-S	9	6.80	0.9	18	405 x (1±10%)
012-H	12	9.6	1.2	27.7	960 x (1±10%)	012-S	12	9.00	1.2	24	720 x (1±10%)
015-H	15	12.0	1.5	34.6	1500 x (1±10%)	015-S	15	11.3	1.5	30	1125 x (1±10%)
024-H	24	19.2	2.4	55.2	3840 x (1±10%)	024-S	24	18.0	2.4	48	2880 x (1±10%)

Notes:1) The data shown above are initial values.

2) To supply rated step voltage to coil is the foundation of relay proper operation. Please make sure the applied voltage to the coil reach at rated values.

Please refer to the typical diagram below for single side stable relay. The "V\_coil" is the rated voltage:



- 3) In case 5V of transistor drive circuit, it is recommended to use 4.5V type relay, and 3V to use 2.4V type relay.
- 4) For monostable relays, if you need to drop down voltage and hold mode after reliably operating, make sure that the effective value of holding voltage is not less than 60% of the rated voltage.
- 5) Maximum voltage refers to the maximum voltage which relay coil could endure in a short period of time.
- 6) When user's requirements can't be found in the above table, special order allowed.
- 7) During the relay pick-up or drop-out processes, there are stages of contact pressure change, contact vibration and unstable contact etc. When the voltage applied to coil is gradually changed, it will lengthen the unstable stage and affect relay endurance. To reduce this influence, please apply step voltage(switching circuit) to relay coil.

# **ORDERING INFORMATION**

		HFD27 /	012	-S	(XXX)					
Туре										
Coil voltage	3, 5, 6, 9, 12, 15, 24, 48VDC <sup>1)</sup>									
Coil power	il power M: Standard (280mW to 580mW) S: Sensitive (200mW) H: High sensitive (150mW)									
Special code <sup>2)</sup> XXX: Customer special requirement         Nil: Standard										

Notes: 1) 48VDC coil voltage is only for standard version.

2) The customer special requirement express as special code after evaluating by Hongfa.

3) Standard tube packing length is 527mm. Any special requirement needed, please contact us for more details.

4) For products that should meet the explosion-proof requirements of "IEC 60079 series", please note [Ex] after the specification while placing orders.Not all products have explosion-proof certification, so please contact us if necessary, in order to select the suitable products.

### **OUTLINE DIMENSIONS, WIRING DIAGRAM AND PC BOARD LAYOUT**

**Outline Dimensions** 



- Remark: 1) The pin dimension of the product outline drawing is the size before tinning (it will become larger after tinning), and the mounting hole size is the recommended design size of the PCB board hole. The specific PCB board hole design size can be mapped and adjusted according to the actual product.
  2) In case of no tolerance shown in outline dimension: outline dimension ≤1mm, tolerance should be ±0.2mm; outline dimension >1mm

  - and ≤5mm, tolerance should be ±0.3mm; outline dimension >5mm, tolerance should be ±0.4mm.
    3) The tolerance without indicating for PCB layout is always ±0.1mm.
    4) The width of the gridding is 2.54mm.

# **CHARACTERISTIC CURVES**



MAXIMUM SWITCHING POWER

### ENDURANCE CURVE



Unit: mm

### **CHARACTERISTIC CURVES**





ENDURANCE CURVE



Resistive load, at 85°C, 1s on 9s off.

### Notice

- 1) To avoid using relays under strong magnetic field which will change the parameters of relays such as pick-up voltage and drop-out voltage.
- 2) Energizing coil with rated voltage is basic for normal operation of a relay, please make sure the energized voltage to relay coil have reached the rated voltage. Regarding latching relay, in order to maintain the "set" or "reset" status, impulse width of the rated voltage applied to coil should be more than 5 times of "set" or "reset" time.
- 3) For a monosteady state relay, after the relay is reliably operated, if it needs to be kept under pressure, make sure that the effective value of the voltage is not less than 60 % of the rated voltage;
- 4) The relay may be damaged because of falling or when shocking conditions exceed the requirement.
- 5) Please use wave soldering or manual soldering for straight-in relay. If you need reflow welding, please confirm the feasibility with us.
- 6) Contact is recommended for suitable condition and specifications if water cleaning or surface process is involved in assembling relays on PCB.
- 7) Regarding the plastic sealed relay, we should leave it cooling naturally untill below 40°C after welding, then clean it and deal with coating, remarkably the temperature of solvents should also be controlled below 40°C. Please avoid cleaning the relay by ultrasonic, avoid using the solvents like gasoline, Freon, and so on, which would affect the configuration of relay or influence the environment.
- 8) When applied with continuous current, the heat from relay coil will age its isolation. Thus, please do not ground connected the coil to reduce electrical errosion if possible. And please provide protection circuit to avoid broken wire and losses.
- 9) Please make sure that there are no silicon-based substances (such as silicon rubber, silicone oil, silicon-based coating agents, silicon fillers, etc.) around the relay, because it will generate silicon-containing volatile gas, which may cause poor contact in case of silicon-containing volatile gas sticking on contact
- 10) About preferable condition of operation, storage and transportation, please refer to "Explanation to terminology and guidetines of relay".
- 11) During the relay pick-up or drop-out processes, there are stages of contact pressure change, contact vibration and unstable contact etc. When the voltage applied to coil is gradually changed, it will lengthen the unstable stage and affect relay endurance. To reduce this influence, please apply step voltage(switching circuit) to relay coil.

### Disclaimer

The specification is for reference only. See to "Terminology and Guidelines" for more information. Specifications subject to change without notice. We could not evaluate all the performance and all the parameters for every possible application. Thus the user should be in a right position to choose the suitable product for their own application. If there is any query, please contact Hongfa for the technical service. However, it is the user's responsibility to determine which product should be used only.

© Xiamen Hongfa Electroacoustic Co., Ltd. All rights of Hongfa are reserved.